

DOSE REPORT USER GUIDE

The dosimetry results presented in the "participant dose report" are in alphabetical order and by type (participant, visitor and control). The area dosimetry results are presented in the part "area dose report". This report is covered by the COFRAC accreditation Essais, n°1-1545, available on www.cofrac.fr (obtained against the NF EN ISO/CEI 17025:2017 standard), except for values in bold orange or in italics (see table below).

Dose report's keys

Participant identification	
• LANDAUER participant n°	Number assigned by LANDAUER to a participant
• Participant n°	Customer-customised field (numbers or letters) for your Radiation protection expert to assign to a participant (blank if no data is provided) - Data provided by the customer
Dosimeter identification	
	<ul style="list-style-type: none"> Type of dosimeter (e.g: IPLUS) + periodicity (e.g: 1 MONTH for monthly) + type of clip (e.g: ALLIGATOR for an alligator clip) + wearing position (e.g: CHEST) Dosimeter reference : DAFAMPPAAA100, for example
Type of radiation	
	Type of ionising radiation. Where several rays (X, beta, gamme, neutrons) have been detected, the first line provides the overall dose by dosimeter, and the following line specify the doses by type of radiation (cf table key of codes and colours used - Unit Type of rays).
Individual or area dose equivalent	
	Operational quantity for external occupational monitoring expressed in millisievert (1 millisievert = 1mSv = 0.001Sv)
• Monitoring period	Period during which the dosimeter has been worn
• Year to date	Cumulative total over 12 consecutive months of the monitoring period, subject to the dosimeters reception and analysis <ul style="list-style-type: none"> For one participant, cumulative total established from the participant number for all monitoring subscriptions. No combined total for the area and control dosimeters
• Authorized by	Initials of the LANDAUER employee who has validated the results
• Hp(10)	Personal dose equivalent at 10 mm depth, used to provide an estimate of effective dose
• Hp(0.07)	Personal dose equivalent at 0.07 mm depth, used to provide an estimate of skin and extremities dose
• Hp(3)	- <i>Optional column according to the order or not of Vision dosimeter for the subdivision</i> - Personal dose equivalent at 3 mm depth, used to provide an estimate of the lens of the eye dose
• H*(10)	Area dose equivalent H*(10), used to provide an estimate of area dose

Codes and colours used

Personnal or ambient dose equivalent	M	Dose equivalent for the monitoring period below the minimum reporting threshold of dosimeter <ul style="list-style-type: none"> Inlight / IPLUS : 0.05 mSv for X, beta and rays MonoRing : 0.10 mSv for X, beta and gamma rays Vision : 0.10 mSv for X, beta and gamma rays Neutrak : 0.10 mSv for neutrons
	Bold red	Personal dose equivalent over 12 consecutive months above or equal to the dose limits of category A indicated below on the summary table
	Bold black	Personal dose equivalent over 12 consecutive months above or equal to the dose limits of category B indicated below on the summary table
Information	Green	Data updated since the previous version of the dose report considered
	Blue	Dose updated since the previous version of the dose report considered
	Bold orange	Dose updated since the previous version of the dose report considered and validated by occupational physician from an unaccredited dose measurement or evaluation process. LANDAUER cannot be held responsible for this value
	Italic	Doses from a measurement process outside COFRAC Accreditation NF EN ISO / IEC 17025:2017
Radiation type	P	Total of registered doses for X, beta and gamma rays
	NF	Total of registered doses for intermediate and fast neutrons
	NT	Total of registered doses for thermal neutrons (or slow neutrons)
	N	Total of registered doses for the intermediate, fast (NF) and thermal (NT) neutrons N= NF+NT
	PN	Total of registered doses for the X, beta, gamma (P) rays and neutrons (NF or NT) PN= P+NF or PN=P+NF+NT
Anomaly code	NR	Dosimeter not returned to our laboratory
	(DE)	Impaired but analysable dosimeter detector
	DE	Impaired and non-analysable dosimeter detector
	DP	Dosimeter impaired during the analysis process, and not analysable

Dose limits over twelve consecutive months

Category or type of workers involved	Whole body Hp(10)	Extremities Hp(0.07) (hands, wrists, etc.)	All cm ² of skin Hp(0.07)	Eye lens Hp(3)
A workers	20 mSv	500 mSv	500 mSv	20 mSv
B or young workers (between 15 and 18 years)	6 mSv	150 mSv	150 mSv	15 mSv
Pregnant women	Dose equivalent to the foetus less than 1 mSv, from declaration of pregnancy to childbirth			

